

SWSI & DWDI Airflow Measurement with Temperature and Alarm Capability

**OVERVIEW**



- Thermal Dispersion Technology
- Designed for SWSI and DWDI Fans
- NIST-traceable Calibration
- %-of-reading Accuracy
- Airflow and Status Alarm
- Temperature Output Capability
- Analog and RS-485 Output Models
- Five Mounting Styles
- Remote Transmitter with LCD Display
- 3-year Warranty



The HTx104-F/SI and HTx104-F/DI are EBTRON’s most economical solution for accurate and repeatable airflow measurement in SWSI and DWDI fans. Airflow, temperature and/or airflow alarming are available on all models. Does not affect fan performance.

**Typical Applications**

- ◆ Fan Airflow Tracking
- ◆ Air Change Verification & Monitoring
- ◆ Fan Performance Monitoring

**Benefits**

- ◆ Demonstrate Fan Performance and Operation
- ◆ Improve Fan Tracking on VAV Systems
- ◆ Comply with ASHRAE Standards
- ◆ Save Energy
- ◆ Reduce Fan Horsepower

**Product Highlights**

- ◆ Accurate and Repeatable
- ◆ Long-term Stability
- ◆ Streamline Design
- ◆ Adjustable Mounting Brackets
- ◆ “Plug and Play” Operation
- ◆ Intuitive User Interface
- ◆ FEP Plenum Rated Cables



# SPECIFICATIONS: HTx104-F (/SI & /DI)

## General

### Probe and Sensor Node Configurations

**SWSI and DWDI fans:** 2 probes x 1 sensor node/per probe in each fan inlet

### Installed Airflow Accuracy<sup>1</sup>

±(3% to 10%) of reading, depending on fan type and installation. May be improved by field adjustment using the Field Adjust Wizard (FAW) to a reliable reference.

### Sensor Node Averaging Method

**Airflow:** Independent, arithmetic average  
**Temperature:** Independent, velocity weighted average

### Listings and Compliance

**UL:** UL-873 and CSA C22.2 No. 24  
**CE:** Non-UK European shipments only  
**UKCA:** UK shipments only  
**BACnet International:** BTL Listed (HTN104 transmitter)  
**FCC:** This device complies with Part 15 of the FCC rules  
**RoHS:** This device is RoHS2 compliant

### Environmental Limits

**Temperature:**  
**Probes:** -20 to 160 °F [-28.9 to 71.1 °C]  
**Transmitter:** -20 to 120 °F [-28.9 to 48.9 °C]  
**Humidity:** (non-condensing)  
**Probes:** 0 to 100%  
**Transmitter:** 5 to 95%

## Individual Sensing Nodes

### Sensing Node Sensors

**Self-heated sensor:** Precision, hermetically sealed, bead-in-glass thermistor  
**Temperature sensor:** Precision, hermetically sealed, bead-in-glass thermistor

### Sensing Node Housing

**Material:** Glass-filled Polypropylene  
**Sensor Potting Materials:** Waterproof marine epoxy

### Airflow Measurement

**Accuracy:** ±2% of reading to NIST-traceable airflow standards (includes transmitter uncertainty)  
**Calibrated Range:** 0 to 10,000 fpm [0 to 50.8 m/s]  
**Calibration Points:** 16

### Temperature Measurement

**Accuracy:** ±0.15°F [0.08 °C] to NIST-traceable temperature standards (includes transmitter uncertainty)  
**Calibrated Range:** -20 to 160 °F [-28.9 to 71.1 °C]  
**Calibration Points:** 3

## Sensor Probe Assembly

### Mounting Rods

**Material:** Zinc plated steel

### Mounting Brackets (Throat, Forward, Face, Flare)

**Material:** 304 stainless steel

### Mounting Brackets (Cantilever)

**Material:** Zinc plated steel

### Mounting Options & Size Limits

**Throat:** 6 to 66 inches [152.4 to 1676.4mm] (throat diameter)  
**Forward:** 6 to 64 inches [152.4 to 1625.6 mm] (diameter at inlet entrance)  
**Face:** 11 to 77 inches [279.4 to 1955.8] (diameter at inlet entrance)

**Flare:** 6 to 57 inches [152.4 to 1447.8 mm] (opening size at backdraft damper inlet)

**Cantilever:** 11 to 82 inches [279.4 to 2082.8 mm] (diameter at inlet entrance)

### Probe to Transmitter Cables

**Type:** FEP jacket, plenum rated CMP/CL2P, UL/cUL listed, -67 to 302 °F [-55 to 150 °C], UV tolerant  
**Standard Lengths:** 10, 25, and 50 ft. [3.1, 7.6 and 15.2 m]  
**Connecting Plug:** 0.60" [15.24 mm] circular DIN

## Transmitter

**Power Requirement:** 24 VAC (22.8 to 26.4 under load) @11V-A

**PCB Connections:** Gold-plated PCB interconnects and test points

**User Interface:** 16-character LCD display and 4 button interface

### B.A.S. Connectivity Options

**HTA104 Transmitter:** Two field selectable (0-5/0-10 VDC or 4-20mA), scalable and isolated analog output signals (AO1=airflow, AO2=temperature or alarm)

**HTN104 Transmitter:** One field selectable (BACnet MS/TP or Modbus RTU) and isolated RS-485 network connection- Individual sensor node airflow rates and temperatures are available via the network

### Airflow Alarm

**Type:** Low and/or high user defined setpoint alarm

**Tolerance:** User defined % of setpoint

**Delay:** User defined

**Zero Disable:** Alarm can be disabled when the airflow rate falls below the low limit cutoff value (unoccupied periods)

**Reset Method:** Manual or automatic

**Visual Indication:** Yes, LCD display

**Network Indication:** Yes (HTN104 only)

**Analog Signal Indication:** Yes, on AO2 assignment (HTA104 only)

### System Status Alarm

**Type:** Sensor diagnostic system trouble indication

**Visual Indication:** Yes, LCD display

**Network Indication:** Yes (HTN104 only)

**Analog Signal Indication:** Yes, on AO2 assignment (HTA104 only)

<sup>1</sup> Installed airflow accuracy is the actual system accuracy expected and includes sampling uncertainty of the sensor probes.